

To: - Telephone System Customers

Ref: Panasonic KXTDA System

Please follow the below steps to change the time on your Panasonic KXTDA telephone system:-

Setting the Time:

Please follow the instructions below to change the system time and date on a Panasonic KX-TDA 15, KX-TDA 30, KX-TDA 100, KX-TDA 200 and KX-TDA 600 PBX's.

**These instructions can only be carried out using the following large display handset models:
KX-DT333, KX-DT343, KX-DT346, KX-NT343, KX-NT346.
KX-T7630, KX-T7633, KX-T7636.**

Press **PROGRAM** or **PAUSE**

Enter **

Enter system password (default 1234)

Enter 000

Press **ENTER**

Enter year (00-99)

Press **SELECT** for month

Press the right arrow on navigation button

Enter date (00-31)

Press **ENTER**

Press **NEXT** (down arrow on navigation button)

Enter hour (00-23)

Enter minute (00-59)

Press **ENTER**

Press **END** (Hold)

Note: The system time can also be set using the PC-based administration access.

If you have any difficulties following the above information or require any additional changes made to your telephone system, please call us on 08456 789 884 to arrange a service call.

Kind Regards,
DataKom Support